

HDM-DAD

SET UP GUIDE INFORMATION

Thank you for purchasing the HDM-DAD. The first of its kind, the HDM-DAD HDCP/EDID line driver with built in diagnostics corrects for corrupt data from inferior loading on the HDCP and EDID communication channel.

- ▲ Designed for easy set-up and operation; wall mount or table mount
- ▲ Direct Coupled from input to output offering maximum video bandwidth
- ▲ Full Balanced Line Transition-Minimized Differential Signaling (TMDS®)
- ▲ Designed for HDTV 480i, 480p, 720p, 1080i, and 1080p
- ▲ Compatible with Computer Resolutions VGA, SVGA, XGA, SXGA and UXGA
- ▲ Four LED-HDMI® Status Indicators: Verifies +5Volts, Hot Plug, Monitors HDCP EDID
- ▲ Automatically Corrects HDCP and EDID data integrity


Set-Up Guide

Simply Connect your HDM-DAD

Install the HDM-DAD between the input and output of HDMI® devices

Top of the unit

1. Red LED glows when Hot Plug is detected.
2. Green LED glows when the 5 volts are detected.
3. Yellow and Blue Data LED's verify EDID and HDCP and will flash every 2 seconds after initial start-up has completed confirming the operation.



Troubleshooting

LED	ON	OFF	FLASHING
Red – Hot Plug		XX	Sink Problem
Green – 5 Volt		XX	Source Problem
Yellow – EDID	XX(NG)	X(GOOD)	
Blue – HDCP	XX(NG)	X(GOOD)	



460 Walker Street
Holly Hill, FL 32117-2653
866.839.9187
www.etherealthome theater.com

For the most reliable and highest quality performance cables, look for the DPL Seal of Approval.

For more information on the Ethereal DPL approved cable products, please visit www.dpllabs.com/page/dpl-member-ethereal.



One Year Manufacturer's Warranty Proudly Made in the U.S.A.